

Product Name: **DECO BH**

---

The products listed contains a light source of energy efficiency class:




XCBD11


---

## Disassembly Instructions:

1. Ensure power is off prior to disassembly.
2. Remove 4 bolts securing trim and diffuser.
3. Undo terminations.
4. Disconnect wiring terminals.
5. Remove screws mounting body to surface.
6. Unscrew all visible screws and nuts to segregate all component parts.



Replaceable (LED only) light source by a professional



Non replaceable control gear