

Product Name: **DOWNLIGHT BL**

The products listed contains a light source of energy efficiency class:




XCBDL20WW / NW



XCBDL10WW / NW

Disassembly Instructions:

1. Ensure power is off prior to disassembly.
2. Slowly pull down until retention clips are exposed then pinch together to remove with ease.
3. Open terminal housing cover.
4. Undo terminations.
5. Unscrew screws on back of downlight.
6. Unscrew all visible screws and nuts to segregate all component parts.



Replaceable (LED only) light source by a professional



Replaceable control gear by professional
