

Product Name: **HIGH BAY**


The products listed contains a light source of energy efficiency class:



XCHBA 100 / 150 / 200 NW

Disassembly Instructions:

1. Ensure power is off prior to disassembly.
2. Remove power cable.
3. Detach suspension.
4. Remove all diffuser screws and diffuser.
5. Remove LED module screws along with the module.
6. Control gear will be located behind the module.
7. Unscrew all visible screws and nuts to segregate all component parts.



Replaceable light source by a professional



Replaceable control gear by a professional
